



VIPER 640 QUICK TUNING GUIDE

This guide is for the new open-body style turnbuckles. 3/32" Staymasters for Lowers 1 turn = half hole

TWS	UPPERS	LOWERS	HEADSTAY
0-10	-6	-2	0
10-12	BASE	BASE	BASE
13-15	+2	+1	BASE
15+	+6	+3	+3

All turns are from base setting

Uppers 28 on PT-1

Lowers 3 fingers 1 m up PT-1

Headstay 21 on PT-1

Back of Mast to Straight Line between Spreader 280 mm

Max Headstay Length, bearing point to bearing point 7588 mm

Arc Measurement- Tack pin for main to forestay, Mark on forestay to forestay pin 1320 mm

