## SNIPE QUICK SETUP GUIDE



COMPONENT	SETTING
Spreader length	16 1/2"-16 <sup>7</sup> / <sub>8</sub> " [42cm-43cm]
Spreader angle	29"-30 ½" (73.5cm-77.3cm)
Jib halyard (final rake)	21' 5"-21' 7" (652cm-658 cm) *
Pre-bend/rig tension	1 $\frac{1}{2}$ -2 $\frac{1}{2}$ " (38mm-63mm) pre-bend, 21 units on the PT-1 Loos gauge
Deck attachment location for shroud	From forestay/jibstay pin to shroud pin: 5' 5 ³/₄"-5' 6 ¹/₄"
Mast butt	Persson center of transom to pin measurement: 10' 8 1/8" (327.4cm) Jibetech center of indent to pin: 10' 8 1/8" (325.5 cm)
Jib tack	11" (27. cm) aft of stem
Whisker pole	Maximum class rule length: 104" (264.1cm)
Proctor mast	Rake: 21' 6" (655cm)   Spreaders length: 16 ¾" Tip to tip: 29 ¾"   Tension: 21"-22"
Sidewinder & Cobra II	Rake: 21' 6" (655cm)   Spreader length: 16 <sup>3</sup> / <sub>4</sub> " -16.5" Tip to Tip: 29.5"   Tension: 21"-22"

<sup>\*</sup>The jib halyard measurement here is for McLaughlin, Persson, Eclipse or Jibe Tec boats. If you have a Phoenix, Lillia, or a Mueller boat, add 1" to the given measurements. For a Skipper Snipe, subtract ¾" (2cm).

