

VIPER 640 QUICK TUNE CHART



TWS Knots	UPPERS	LOWERS	HEADSTAY
0 to 10	- 6	- 2	0
0 to 12	Base	Base	Base
13 to 15	2	1	Base
15 +	6	3	3

BASE SETTINGS

UPPERS	LOWERS	HEADSTAY	RAKE
28 on the PT-1	3 fingers 0.1 cm up PT-1	21 on the PT-1	28 cm from the back of the mast to the center of the spreaders

NOTES

Max Headstay Length, bearing point to bearing point 758.8 cm
 Arc Measurement- Tack pin for main to forestay, Mark on forestay to forestay pin 132 cm